## Supporting Information

## One-pot Synthesis of Double-network Hydrogel Electrolyte with Extraordinarily Excellent Mechanical Properties for Highly Compressible and Bendable Flexible Supercapacitor

Tingrui Lin,<sup>†</sup> Mengni Shi,<sup>†</sup> Furong Huang,<sup>†</sup> Jing Peng,<sup>†</sup> Qingwen Bai,<sup>‡</sup> Jiuqiang Li,<sup>†</sup> and Maolin Zhai<sup>\*,†</sup>

<sup>†</sup> Beijing National Laboratory for Molecular Sciences, Radiochemistry and Radiation Chemistry Key Laboratory of Fundamental Science, The Key Laboratory of Polymer Chemistry and Physics of the Ministry of Education, College of Chemistry and Molecular Engineering, Peking University, Beijing 100871, China.

<sup>‡</sup> Beijing National Laboratory for Molecular Sciences, The Key Laboratory of Polymer Chemistry and Physics of the Ministry of Education, College of Chemistry and Molecular Engineering, Peking University, Beijing 100871, China.

\* Corresponding Author: E-mail: mlzhai@pku.edu.cn



**Figure S1.** Tensile stress-elongation cures of the Li-AG/PAM DN hydrogel electrolyte and the hydrogel electrolyte synthesized by the same method of the Li-AG/PAM DN hydrogel electrolyte without the addition of MBA crosslinker.



**Figure S2.** Successive cyclic tensile tests of the Li-AG/PAM DN hydrogel electrolyte at a maximum elongation of 500%, 1000%, 1500%, 2000%, and 2500%, respectively.

**Table S1.** Energy dissipation values of the Li-AG/PAM DN hydrogel electrolyte during cyclic tensile tests at different maximum elongations.

Maximum Elongation (%)	500	1000	1500	2000	2500
Energy Dissipation (MJ/m <sup>3</sup> ) <sup>a</sup>	45.96	70.73	106.68	168.56	247.70

<sup>a</sup> During each tensile cycle, hydrogel electrolyte specimens were stretched to a maximum elongation ( $\lambda_{max}$ ) and then returned to the original height, so the energy dissipation ( $E_d$ ) was estimated by area between the loading-unloading curves ( $E_d = \oint_0^{\lambda_{max}} \sigma \, d\lambda$ ), where  $\sigma$  and  $\lambda$  are tensile stress and elongation, respectively.



**Figure S3.** Compression stress-compression strain curves of (a) the Li-AG hydrogel electrolyte and (b) the Li-PAM hydrogel electrolyte and tensile stress-elongation curves of (c) the Li-AG hydrogel electrolyte and (d) the Li-PAM hydrogel electrolyte.

Hydrogel	Tensile properties		<b>Compression properties</b>		
electrolyte	Tensile strength (kPa)	Elongation at break (%)	Compression strength (MPa)	Fracture compression strain (%)	
Li-AG	27±2 <sup>a</sup>	34±3	0.0058±0.0007	27±3	
Li-PAM	319±44	2186±91	131±5	above 99.9 <sup>b</sup>	
Li-AG/PAM DN	1103±24	2780±55	150±7	above 99.9	

**Table S2.** Mechanical properties of the Li-AG hydrogel electrolyte and the Li-PAM hydrogel electrolyte.

<sup>a</sup> All Error bars show standard deviation; sample size n = 3.

<sup>b</sup> The fracture compression strain of hydrogel electrolytes is too high to be precisely measured.



**Figure S4.** Assembly process diagram of (a) the Li-AG/PAM DN hydrogel electrolyte-SC and (b) the Li-AQ electrolyte-SC.



**Figure S5.** Assembly process diagram of the two-electrode testing configuration for (a) the Li-AG/PAM DN hydrogel electrolyte-SC and (b) the Li-AQ electrolyte-SC.



**Figure S6.** (a) Specific capacitance and (b) GCD curve of the Li-AG/PAM DN hydrogel electrolyte-SC applying various thickness of the Li-AG/PAM DN hydrogel electrolyte at a current density of  $0.2 \text{ A g}^{-1}$ .



**Figure S7.** Equivalent circuit model and fitting parameters of the AG/PAM DN hydrogel electrolyte-SC and the Li-AQ electrolyte-SC. Both *Rs* and *Rct* represent resistance. Both *CPE*1 and *CPE*2 represent constant phase element (CPE). *W* represents Warburg impedance.

**Table S3.** The values of *R*s, *R*ct, and *W* of the AG/PAM DN hydrogel electrolyte-SC and the Li-AQ electrolyte-SC fitted by Nova 2.1.2 software.

		$Rs(\Omega)$	$Rct(\Omega)$	$Y_0 (\Omega^{-1} s^{0.5})$ of $W^{a}$
LI-AG/PAM DN hydrogel electrolyte-SC 3.33 0.58 0.17	Li-AG/PAM DN hydrogel electrolyte-SC	3.33	0.58	0.17
Li-AQ electrolyte-SC 2.07 1.08 0.06	Li-AQ electrolyte-SC	2.07	1.08	0.06

<sup>a</sup> The  $W(\Omega)$  is defined as  $W = \frac{1}{Y_0(jw)^{0.5}}$ , where j,  $w(s^{-1})$ ,  $Y_0(\Omega^{-1} s^{0.5})$  are imaginary unit, angular frequency, and coefficient of the W, respectively.



**Figure S8.** *ESR* of the Li-AG/PAM DN hydrogel electrolyte-SC and the Li-AQ electrolyte-SC obtained from the Nyquist plots in a frequency range from  $10^6$  to  $10^{-2}$  Hz.



**Figure S9.** GCD curves of (a) the Li-AG/PAM DN hydrogel electrolyte-SC and (b) the Li-AQ electrolyte-SC before and after 5000 cycles at a current density of  $0.2 \text{ A g}^{-1}$ .



**Figure S10.** GCD curves of the Li-AG/PAM DN hydrogel electrolyte-SC on cycling after (a) over-charge test at a current density of 0.3 A  $g^{-1}$ , (b) short circuit test at a current density of 0.3 A  $g^{-1}$ , and (c) high temperature of 60 °C test at a current density of 0.2 A  $g^{-1}$ .



**Figure S11.** Assembly process diagram of the Li-AG/PAM DN hydrogel electrolyte-SC for compression tests. The bottom of the photo shows the SC during electrochemical tests under a compression strain of 25%.



**Figure S12.** GCD curves of the Li-AG/PAM DN hydrogel electrolyte-SC at various (a) compression strain, (b) compression cycles, (c) bending angle, and (d) bending cycles.



**Figure S13.** Assembly process diagram of the Li-AG/PAM DN hydrogel electrolyte-SC for bending tests. The most right photo shows how electrochemical tests were carried out in the SC bended to 45°.